



**US  
DENTAL  
DEPOT**

**US DENTAL DEPOT**

6555 NW 9<sup>th</sup> Avenue suite 212  
Fort Lauderdale 33309  
Florida USA

USA - 1 1866 625 5558 – 1 954 874 6325

Colombia 57 1 489 9051

Peru 51 1 707 3444

Venezuela 58 212 729 1639

Argentina 54 11 5258 7148 Cba 54 351 569 1409

[www.USDENTALDEPOT.com](http://www.USDENTALDEPOT.com)



## **Eltropol E**

Electrolytic polishing unit for one cobalt chrome casting. Superb polishing results through object movement, bath heating and extremely efficient ring cathode. Quick acting short circuit cut out and automatic current control with three power settings. High degree of safety through firm contact with object clamps. Speedy completion of polishing work in 2 x 4-6 minutes and LED current indicator and times.

Height: 230mm, 9"  
Width: 300mm, 12"  
Depth: 250mm 10"  
Max power: 170W  
Capacity: 1 liter  
Weight: 6.5kg 14lbs

Item #: 101347